Clocks and Timers

The Embedded Discovey Book

What is Clock?

- Computers use an internal clock to synchronize all of their calculations.
- The clock ensures that the various circuits inside a computer work together at the same time.

What is Clock?

• The unit of measurement called a hertz (Hz).

For loop isn't good for creating delays

```
#[inline(never)]
fn delay(tim6: &tim6::RegisterBlock, ms: u16) {
   for _ in 0..1_000 {}
}
```

No Operation

There is a way to prevent LLVM from optimizing the for loop delay: add a *volatile* assembly instruction. Any instruction will do but NOP (No OPeration) is a particular good choice in this case because it has no side effect.

Your for loop delay would become:

```
#[inline(never)]
fn delay(_tim6: &tim6::RegisterBlock, ms: u16) {
   const K: u16 = 3;
   for _ in 0..(K * ms) {
        aux9::nop()
   }
}
```

Hardware Timer

The basic function of a (hardware) timer is ... to keep precise track of time. A timer is yet another peripheral that's available to the microcontroller; thus it can be controlled using registers.

TIM6

We'll be using one of the *basic* timers: TIM6. This is one of the simplest timers available in our microcontroller

The registers we'll be using in this section are:

• **SR**, the status register.

The registers we'll be using in this section are:

- **SR**, the status register.
- EGR, the event generation register.

The registers we'll be using in this section are:

- SR, the status register.
- EGR, the event generation register.
- CNT, the counter register.

The registers we'll be using in this section are:

- SR, the status register.
- EGR, the event generation register.
- CNT, the counter register.
- PSC, the prescaler register.

Step 1:

Set the timer trough auto reload register **ARR**

Step 2:

We have to enable the counter register

(CR1.CEN = 1)

Step 3:

We have to reset the value of count register **CNT** to zero.

On each tick it's value get incremented.

Step 4:

Once the CNT register has reached the value of the ARR register, the counter will be disabled by hardware

```
(CR1.CEN = 0)
```

and an update event will be raised

CNT register increase at a Frequency

CNT register increase at a frequency of **apb1 / (PSC +1)** times per second.

Also note: 1 Khz = 1 ms (period)

Configure the prescaler to have the counter operate at 1 KHz

Where:

APB1_CLOCK = 8 MHz

PSC = ?

8_000_000/ (PSC + 1) = ?

Formula: apb1 / (PSC +1)

Configure the prescaler to have the counter operate at 1 KHz

Formula: apb1 / (PSC +1)

Where:

APB1_CLOCK = 8 MHz

PSC = ?

 $8_{000} = 1000 + 1 = 1_{000} = 1_{000} = 1 = 1_{000} =$

The counter (CNT) will increase on every millisecond