Chapter # 15

LED COMPASS


Compass

A compass is an instrument used for navigation and orientation that shows direction relative to the geographic cardinal directions. Usually, a diagram called a compass rose shows the directions north, south, east, and west on the compass face as abbreviated initials.




Working of a Compass

Compasses work so effortlessly because their design allows the magnet to respond freely to Earth's magnetic field. Earth itself is like a giant magnet that creates its own magnetic field. The north end of a **compass** is drawn to align with Earth's magnetic North Pole.



Earth's Magnetic Field

Earth's magnetic field, also known as the **geomagnetic field**, is the magnetic field that extends from the Earth's interior out into space, where it interacts with the solar wind, a stream of charged particles emanating from the Sun.




LED Compass

We'll implement a compass using the LEDs on the F3. Like proper compasses, our LED compass must point north somehow. It will do that by turning on one of its eight LEDs; the on LED should point towards north.

Magnetic Field

A magnetic field is a vector field that describes the magnetic influence of electric charges in relative motion and magnetized materials. The effects of magnetic fields are commonly seen in permanent magnets, which pull on magnetic materials (such as iron) and attract or repel other magnets.




LSM303DLHC Package

Magnetic fields have both a magnitude, measured in Gauss or Teslas, and a direction. The magnetometer on the F3 measures both the magnitude and the direction of an external magnetic field but it reports back the decomposition of said field along its axes. As shown in console.

```
$ # itmdump terminal
(..)
I16x3 { x: 45, y: 194, z: -3 }
I16x3 { x: 46, y: 195, z: -8 }
I16x3 { x: 47, y: 197, z: -2 }
```


Take 1

If we only looked at the signs of the X and Y components we could determine to which quadrant the magnetic field belongs to.



Take 2

We'll use math to get the precise angle that the magnetic field forms with the X and Y axes of the magnetometer. We'll use the atan2 function. This function returns an angle in the -PI to PI range.



Magnitude

- The number that the magnetic_field function reports are unit-less.
- We convert those values to Gauss.
- Magnetic gain setting that has different values according to the values of the GN bits. By default, those GN bits are set to 001.
- We need to do is divide the X, Y and Z values that the sensor outputs by its corresponding gain.
- The magnitude of the Earth's magnetic field is in the range of 250 mG to 650 mG (the magnitude varies depending on your geographical location)

Calibration

- The direction of the Earth's magnetic field with respect to the magnetometer should change but its magnitude should not
- The magnetometer indicates that the magnitude of the magnetic field changes as the board rotates.
- The calibration involves quite a bit of math (matrices).
- Let's record the readings of the magnetometer while we slowly rotate the board in different directions.

Conclusion

- Reading values from magnetometer.
- Design LED Compass.
- Calculate its Magnitude.
- Calibrate the sensor to get accurate Readings.